














Product Identification		Product Image
Company Name	LUTEC	
Item code	5267103001	
Module code	5267103001M	
Product Name	LEDA	
Last modified	2021/6/24	

Step

	
1. Light	2. Unscrew and remove the plastic base
	
3. Unscrew the shield cover	4. Unscrew the wire on terminal and remove the shield cover
	
5. Unscrew and remove the terminal	6. Unscrew the module
	
7. Solder the wire and remove the module	8. pry off the sensor
	
9. Unscrew and take out the sensor holder	10. Unscrew and take out the lamp holder
	
11. Pull out the LED module	12. Module