

Light source remove Instructions

V1.0 Template(2021)

V1.0 Template(2021)		
Product Identification		Product Image
Company Name	LUTEC	Annual Control of the
Item code	5287901012	
Module code	5287901012M	
Product Name	RIALTO	
Last modified	2022/9/20	
Step		
1. Light		2. Unscrew the tightening screws on two sides, remove the plastic base
3. Pry open the upper end of both sides of the snap, remove the upper plate and shading plate		4. Pry open and remove the upper and lower tempered glass
5. Unscrew and pry open to remove the reflector screw		6. Unscrew the terminal block, unscrew the three screws on the cover and remove it
g in		
7. Unscrew the screws on control board&Led board		8. Solder off the wires on LED board, unscrew and remove the control board and LED boards
**		
9. Module	248V 60mA	