













# LUTEC Light source remove Instructions

CONNECTED BY LIGHTING

V1.0 Template(2021)

Product Identification		Product Image
Company Name	LUTEC	
Item code	8600502012	
Module code	8600502012M	
Product Name	STANOS	
Last modified	2021/9/15	

## Step

	
<p>1. Light</p> 	<p>2.Pry open the diffuser</p> 
<p>3. Unscrew and remove the LED board</p> 	<p>4. Unscrew and remove the fixed board</p> 
<p>5. Unscrew and remove the other fixed board</p> 	<p>6. Unscrew and remove the control board</p> 
<p>7. Unscrew the wires on terminal post</p> 	<p>8. Unscrew and remove the gasket</p> 
<p>9. Unscrew and remove the body shell</p> 	<p>10.Unscrew and remove the gaskets and screws</p> 
<p>11. Withdraw the wires</p>	<p>12. Module 25VDC 27mA</p>